

Fitting Instructions #1984IS

Mazda MX-5 NA, NB

Front Lower Control Arm Bushing

Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Using factory manual, remove the front lower control arm of the front suspension;
- Remove original bushes from the housing with the use of a hydraulic press and suitable pressing tools;
- Apply the grease supplied to the bore of the bush, and the outside of the crush tube;
- Push the new polyurethane bushing into the housing as shown in the illustration, then the crush tube;
- Refit the front lower control arm to the vehicle and tighten all bolts to manufacture's torque settings.
- Carry out wheel alignment.

